


PERFECT PENDULUM SETUP POSITION... PLUS... PERFECT PENDULUM SWING MOTION



Push the middle button to adjust

DESIGNED FOR ALL TYPES OF GRIP POSITIONS

Right-handed
Left-handed
Left hand LOW
Right hand LOW

- GRIP**
- 1 LEFT WRIST PAD**
Depress & hold down the middle logo button. Slide the wrist pad in or out to fit desired position. Release the button.
 - 2 RIGHT WRIST PAD**
Repeat 1st step process.
 - 3 PLACE UNIT ON PUTTER**
Black stem should sit on right side of putter grip (For right-handed golfer).

HOW TO USE THE PUTT MASTER

The key to understanding the Putt Master is to set it up properly. The wrist pad spacing should be slightly wider than you would think is necessary. This position magnifies the feeling of locked wrists and promotes an awareness of your shoulder motion – the true pendulum type swing.





**SCAN HERE TO VISIT
ORANGEWHIPGOLF.COM**

USED BY TOUR PROS



A few helpful hints:

- Use normal grip pressure. Don't strangle the Putt Master or putter. You do not need to lock the two together.
- Initially, try to set the pads slightly wider than you would normally to give an enhanced sensation of locking the wrists in place.
- Putt with the Putt Master in short sessions. Go back and forth between using it and not using it. This gives fast feedback.
- Use the Putt Master without your putter at home and the office.
- If the Putt Master feels awkward holding it in place, slip a rubber band over the black stem and the putter securing the two together.

TEACHES:

PROPER... Arm address position
PROPER... Backswing motion
PROPER... Forward swing motion
PROPER... Follow-through position

ELIMINATES:

IMPROPER... Wrist bending motion
IMPROPER... Arm and shoulder motion
IMPROPER... Putter head rotation

WARNING: Do not throw, bend or twist the Putt Master. It may break or lose its intended functionality. Do not impact anyone or anything with the metal stem. It may cause an injury.